

Your new Kick-Stop is packed in three pieces. Attach the two end pieces to the center piece, turning so the adjusting springs lock into place.

Standing by the cow on the working side, insert one end of the Kick-Stop so that the rubber tip is at the loose skin between the udder and the inner thigh.

Adjust the Kick-Stop with the adjusting springs so that the other end slips over the spine between the pin bone and hip bone. Kick-Stop should be snug with no slack but not excessively tight. When properly adjusted, Kick-Stop prevents the animal from lifting its hind legs, but can be removed with a slight upward and forward motion without readjusting the springs. It is not necessary to move the springs when going from cow to cow of similar size. Kick-Stop is suitable for young stock with proper readjustment.

Always be sure to gently lift the Kick-Stop so that the top end clears the back of the cow before removing from the sensitive groin area.

MAKE SURE THE KICK-STOP FITS SNUG coburn.com